

FUEL INJECTION KIT



Part# FIK



1. Gauge(3-1/2") 4 FT. Hose, 6 FT. Tubing Assembly(120 PSI) With Relief Valve
2. Connecting Hose and Valve Assembly for Bosch CIS
3. Connecting Hose Assembly for GM TBI
4. Adapter-Ford EFI
5. Adapter-Ford EFI
6. Connecting Hose with M12 X 1.5 Nut
7. Adapter-for small Schraeder Valve(Ford)-5/16" x32 UNF FEMALE
8. Adapter-for standard Schraeder Valve-7/6" X 20 UNF FEMALE
9. 10mm bent tubing with 5/8" - 18 male nut X 2 pcs
10. Bent tubing with 5/8" -18 invert flare nut, M16X1.5 Nut and O ring X 2 pcs
11. Adapter-M16X1.5x5/8" - 18 x 2 pcs
12. Adapter-Female M14x1.5 one end and 3/8" Tube fitting other end x 2 pcs
13. Adapter-Female M16x1.5 one end and 3/8" Tube fitting other end x 2 pcs
14. Adapter-Male M14x1.5 & 3/8" Tube fitting plus O ring x 2 pcs
15. Adapter-Male M16x1.4 & 10mm Tube fitting plus O ring x 2 pcs
16. Adapter for GEO Storm and Isuzu(Isuzu I-Tec Systems)
17. Manifold with quick coupler plug 1/4"x5-16"
18. Manifold with coupler plug 3/8"
19. Quick coupler plug with quick nozzle(90 degree)
20. M14x1.5 Male-M14x1.4 Female with quick plug (for cars: Jaguar & Volvo)
21. Adapter M10X1.0 male-M12x1.5 Male with O ring (for cars: Daimler & Benz)
22. Adapter M10x1.0 Female-M12x1.5 Male (for cars: Ford Standard, Golf 16V)
23. Adapter M8x1.0 Female-M12x1.5 Male(for BMW)
24. Adapter M8x1.0 Male-M12x1.5 Male with O ring x 2 pcs (for cars: Daimler Benz, VW Golf, BMW, Audi 100 5 Cyl. + DPAK14)
25. Adapter M14x1.5 Male-M12x1.5 Male with O ring (for cars: Peugeot, Fiat Croma, Audi 6 Cyl + DPAK12)
26. Adapter M16x1.5 Male-M12x1.5 Male with O ring (for cars: Ford Scorpio-motor DOH 2.0L, Citroen XM, Opel Bj 97,1 4L)
27. Adapter-Barjo Bolt M12x1.25 with Nylotron washer (for cars: Chrysler, Opel-Vauxhall, Honda & Hyundai)
28. Adapter-Barjo Bolt M12x1.5 with Nylotron washer (for Saab)
29. Adapter-Barjo Bolt M10x1.0 with Nylotron washer (for Sterling Triumph)
30. Adapter-Barjo Bolt M8x1.0 with Nylotron washer (for Toyota)
31. Adapter-Barjo Bolt M6x1.0 with O ring (for cars: Ego & Suzuki)
32. Quick plug with 1/4" Hose Barb (for cars: Bosch Mono-Jetronic fur VW Motor RP 2 Stuck)
33. Adapter M8x1.0 Male-M12x1.5 Male with O ring (for cars: Audi Sondera adapter, secondary adapter)
34. Adapter M16x1.5 Female-M12x1.5 Male (for cars: Ford-Scorpio & Citroen-XM)
35. Adapter M14x1.5 Female-M12x1.5 Male (for cars: Opel-Vauxhall, Mit Dichtkuppe)
36. Straight Tubing with 5/8" -18 Male nut